



Instructions to enable / disable hot water outlet on Crem Zircon & EX line espresso machines fitted with electronic hot water valve:

With machine off at the switch on front of machine (on at power point):

- Press and hold One long espresso button on the left hand group head keypad (K3)
- Switch machine on, keeping One long espresso button (K3) pressed for approximately 8 seconds (initially all buttons will briefly illuminate to show the programming is loading, and will then go out. Keep one long espresso button (K3) held in)
- The LED above One long espresso button (K3) will illuminate to confirm programming is successful
- Let go of One long espresso (K3)
- Switch machine off at machine to save the new setting
- Switch machine on

Pressing the continuous dispense button under 1 second will allow hot water to be released from the built in hot water outlet.

Pressing the continuous dispense button over 1 second, but under 8 seconds will allow water to dispense from the corresponding group head.

